




Operating Manual

MIGET



**Please ensure that this
Instruction Manual
is made available
to the user of
the equipment**

£2.50



Contents

	Page
● Warnings.....	3
● Safety.....	4
● Introduction.....	5
● Specification.....	6
● Installation.....	7
● Controls.....	8
● Maintenance.....	11
● Circuit Diagram.....	12
● Spare Parts.....	13



WARNING



This welding equipment has been designed, manufactured and tested to the highest standards to ensure long and trouble free life. However, regular maintenance is an essential part of keeping the machine operating in a reliable and safe manner and your attention is drawn to any maintenance instructions that are contained in this manual.

In general, all welding equipment should be thoroughly inspected, tested and serviced at least annually. More frequent checking will be required when the equipment is heavily used.

Wear and tear, particularly in electro-mechanical and moving components, are gradual processes. Caught in time, repair costs are small and the benefits in performance reliability and safety are significant. Left alone, they can put the equipment, and you, at risk.

Have this equipment regularly inspected and maintained by an approved service centre.



WARNING



ARC WELDING AND CUTTING CAN BE INJURIOUS TO YOURSELF AND OTHERS. TAKE PRECAUTIONS WHEN WELDING. ASK FOR YOUR EMPLOYER'S SAFETY PRACTICES WHICH SHOULD BE BASED ON MANUFACTURERS' HAZARD DATA.

ELECTRIC SHOCK - Can Kill

- Install and earth the welding unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves, or wet clothing.
- Insulate yourself from earth and work.
- Ensure your working position is secure.

FUMES AND GASES - Can be Dangerous to Health

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to keep fumes and gases from your breathing zone and the general area.

ARC RAYS - Can Injure Eyes and Burn Skin

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

NOISE- Excessive noise can damage hearing

- Protect your ears. Use ear defenders or other hearing protection.
- Warn bystanders of the risks.

**READ AND UNDERSTAND THE INSTRUCTION MANUAL
BEFORE INSTALLING OR OPERATING AND SEE WMA PUBLICATION 237
'The arc welder at work' AVAILABLE FROM THE MANUFACTURER.**

PROTECT YOURSELF AND OTHERS

SAFETY

In any arc welding or gouging operation, it is the responsibility of the user to observe certain safety rules to ensure his personal safety and to protect those working near him.

Read all safety articles relevant to arc welding published by the WMA. Pay particular attention to any **CAUTION** or **WARNING** Notes included in this manual. **CAUTION** indicates possible equipment damage. **WARNING** indicates possible hazard to life.

⚠ **WARNING** ⚠

*The ON/OFF switch on this equipment does not isolate the unit from the mains electrical supply. **AC POWER IS PRESENT ON THE ON/OFF SWITCH TERMINALS.***

*The On/Off lamp is an indication that the supply is switched on and does not imply that the unit is isolated from the supply. **BEFORE REMOVING THE COVERS FOR MAINTENANCE, ISOLATE THE UNIT FROM THE MAINS ELECTRICAL SUPPLY.***

1. Electrical

- ⚠ Treat electricity with respect. Even the open circuit voltage of this equipment can be dangerous. Adjustments to the torch or replacement of torch parts should be undertaken with the mains supply isolated from the unit.
If damaged torch cables or torch components are found, the unit must be disconnected from the mains and defective parts must be replaced using only Murex spare parts.
- ⚠ Do not work on live circuits or cables. Disconnect the main power supply before checking the machine or performing any maintenance operation.
- ⚠ Be sure the case of the welding machine is properly connected to a good electrical earth.
- ⚠ Have the wiring for the welding machine installed by a qualified electrician. All connections must be made according to specifications in force and to general safety standards.
- ⚠ Do not stand in water or on damp floors while using an arc welder or cutter. Do not use in the rain.
- ⚠ Do not operate with worn or poorly connected cables. Inspect all cables frequently for insulation failure, exposed wires and loose connections.
- ⚠ Do not overload cables or continue to operate with overheating cables. Cables which are too small for the current carried will overheat, causing rapid deterioration of the insulation.
- ⚠ Pay attention that live parts of the torch do not touch any metal which is connected to the earth cable. Fix an insulated hook to hang the torch on when it is not in use.

1. Ventilation

- ⚠ Do not weld or cut on containers which have held combustible or flammable materials, or materials which give off flammable or toxic vapours when heated, without proper cleaning.
- ⚠ Locate the welding/cutting operation far enough from any vapour-type degreaser using trichloroethylene or other chlorinated hydrocarbons as solvents. The ultraviolet light from the arc can decompose these vapours into toxic gases at a considerable distance from the arc, even though the concentration of the gases is low enough to be undetectable by smell.
- ⚠ Be sure to provide adequate ventilation for removal and dilution of fume and gases. Fume exhaust facilities near the arc, or a ventilated helmet should be used when cutting in confined spaces or on toxic material.

2. Glare

- ⚠ Never look at the arc without wearing eye protection. Always use the proper protective clothing, filter glasses, and gloves. Be careful to avoid exposed skin areas. Do not use cracked or defective helmets or shields.
- ⚠ Never strike an arc when there is someone near who is not protected from the strong light of the arc.
- ⚠ Warn bystanders who are not aware of the dangers of ultraviolet light.

3. General

- ⚠ Take care when lifting the unit.
- ⚠ Ensure that cylinders are secured by chains.
- ⚠ Locate the unit so that there is adequate air flow to the ventilation louvres.
- ⚠ Always dress correctly to protect against glare, radiation and spatter.

4. Fire

- ⚠ Ensure that the correct type of fire extinguisher is available in the welding area.
- ⚠ Do not weld near flammable materials or liquids, in or near explosive atmospheres, or on pipes carrying explosive gases.

5. Vehicle Electrics

- ⚠ When working on motor vehicles, remove the battery and any circuitry which may be damaged by the arc.
- ⚠ Whilst welding be aware of the possibility of 'hidden wires' behind panels or bulkheads.

INTRODUCTION

The MIGET is a MIG/MAG welding power source fitted with an integral wire feed system suitable for welding mild and stainless steel and aluminium.

The MIGET accepts the standard 15Kg 300mm \varnothing wire reel keeping it totally enclosed within the wire feed compartment.

Rugged undergear ensures portability even with the larger size gas cylinders mounted on the cylinder carrier.

The MIGET is supplied complete with the MXA 153 detachable (Euro connector) 3 metre Welding Torch, Work Return Lead and Clamp, Gas Hose plus $\frac{3}{8}$ BSP Nut and Nipple, and Primary Mains Cable.

Protection against the effects of overheating is provided by a thermal protection device. In the event of overheating, power from the MIGET is shut down and the yellow indicator lamp illuminates.

Specification

Input

Voltage	240v
Phase	1
Frequency	50Hz
Fuse Rating	13A
Max KVA	4.5 KVA

Output

OCV	16.6 - 27.0 Volts
Current Range	30 - 170 Amps
Rated Output	
20% Duty Cycle	140A/21v
35%	105A/19v
60%	80A/18v
Standards	EN 60 - 974
Insulation Class	F & H

Dimensions (inclusive of undergear)

Height	520mm
Width	480mm
Length	840mm
Weight	55Kg

Wire Sizes

Steel	0.6/0.8mm
Aluminium	1.0mm


INSTALLATION

WARNING

Installation should only be undertaken by a qualified electrician or trained individual.

Correct installation is important for the reliable and safe operation of the equipment. Before continuing carry out the following checks:

1. Having unpacked the power source, inspect for evidence of damage or missing parts. Notify the carrier or Murex immediately.
2. Check the air louvres in the front and rear panels for any packing materials that might obstruct the air flow.
3. Position the equipment in a safe area. Leave at least 0.5m clearance around the unit to allow air to circulate freely. The position should be free from dust, fumes and heat. See SAFETY at the front of this manual.
4. If the mains cable is not fitted, connect it to the mains input terminal block (marked L and N) leaving sufficient slack in the green and yellow earth wire.

The green and yellow earth wire should be securely fitted to the chassis of the welding machine via the stud and nut marked 

INITIAL SETTING UP

1. Check that the ON/OFF switch is 'off'.

WARNING

This switch does not isolate the unit from the mains electrical supply

2. Feed Roll

Before connecting the gas supplies, ensure that the equipment is set up for the type and size of wire to be used.

3. Work Return Lead

Connect the work return lead between the work return socket and a clean area on the work piece.

WELDING WIRE

Fit the reel of welding wire:

1. Remove the hand nut from the hub.
2. Place the reel of wire on the hub so that the wire will be drawn off from the top. Ensure that the pin on the hub locates in the hole in the side of the reel. Replace hub hand nut.
3. Release the end of the wire from the side of the reel but do not allow the coils to loosen. Cut off the kinked portion and remove any sharp edges from the end of the wire. This must be done every time the wire is threaded through the equipment.
4. Release the pressure roll arm.
5. Thread the wire through the inlet guide over the feed roll and into the outlet guide, for approximately 50mm (2in).

Lock the pressure roll arm so that the welding wire is clamped into position in the groove.

6. Switch on the power source.


TORCH

1. Check that the torch lead is laid out straight and connect the torch to the torch adaptor, ensuring that the wire enters the liner correctly.
2. Remove the nozzle and contact tip from the torch. Using the torch switch, feed the wire through the torch. Thread a contact tip over the wire and screw it into the torch. Tighten the contact tip with the key provided.
3. Fit the nozzle.

WARNING

The wire contact tip, and wire feed mechanism are 'live' when the torch switch is pressed.

4. Press the torch switch.



5. Check that the wire feed is smooth and positive. If the wire slips in the feed roll, tighten the pressure adjusting screw just enough to obtain positive wire feed drive.

Do not overtighten the adjusting screw.

6. Cut off the wire to protrude 10mm from the torch connector.

REPLACEMENTS AND ADJUSTMENTS

1. Guide Tube Removal

- (a) Release the pressure roll.
- (b) If the guide tube will move freely, push it forward out of the torch adaptor using a pencil or soft wooden dowel rod, then withdraw it from the torch adaptor using a pair of long nose pliers.

If the guide tube liner does not move freely, it may be necessary to drive it out using a hard wooden dowel or old guide tube.

Note: Do not use a screwdriver or metal tool to push out the tube. Use of such a tool may damage the end of the guide and impair wire feeding.

2. Feed Roll Changing

Remove the feedroll retaining screw. It will be necessary to give the screwdriver a sharp twist to avoid turning the motor.

Drop the pressure arm and pull off the feedroll. When replacing the feedroll, note the wire size which is stamped on the face of the roll. The required size must face outwards when the roll is refitted. Ensure that the Woodruff Key is not lost.

Fit the feedroll and lock the pressure arm. Refit the retaining screw giving it a sharp twist with the screwdriver to tighten.

3. Feed Roll Pressure

Correct feed roll pressure will provide smooth, uninterrupted feeding of the wire. Inspection of the wire should reveal only slight marks from the feed rolls and no deformation of the wire. Use of the correct pressure is especially important when feeding aluminium wires. **The pressure should be just enough to provide positive wire drive without slipping.**

4. Overrun adjustment

Tighten or unscrew the hub tension nut in the centre of the wire reel hub until sufficient hub friction is achieved to prevent overrun.

Note: Do not overtighten or the wire will slip in the feed rolls resulting in slow or irregular wire feed.

CONTROLS

1. ON/OFF Switch

⚠ **WARNING** ⚠

*The ON/OFF switch on this equipment does not isolate the unit from the mains electrical supply. **AC POWER IS PRESENT ON THE ON/OFF SWITCH TERMINALS.** The On/Off lamp is an indication that the supply is switched on and does not imply that the unit is isolated from the supply. **BEFORE REMOVING THE COVERS FOR MAINTENANCE, ISOLATE THE UNIT FROM THE MAINS ELECTRICAL SUPPLY.***

2. Over Temperature Indicator Lamp

The indicator will illuminate and the power source will be inhibited if the temperature of internal components becomes excessive. Should this occur, leave the power source to idle for a few minutes to cool down, do not switch the power source off as this will remove power from the cooling fan.

CAUTION


If this indicator lamp persistently operates do not use until the power source has been checked by an approved Service Engineer.

3. Wire Feed Speed Control

Provides infinitely variable wire feed speed up to a maximum of 16m/min.

4. Voltage Control Switch

Provides six output voltage levels.



WELDING NOTES

1. Set the voltage and wire feed controls to the appropriate positions for the material to be welded. (See Guidelines on page 10).
2. Cut the electrode wire so that approximately 3-5mm of wire protrudes from the contact tip.
3. Position the torch over the seam to be welded as follows -
 - (a) Hold the contact tip approximately 10mm from the work surface.
 - (b) Hold the torch so that it makes an angle of approximately 70° to the work surface.
 - (c) Position the torch so that the nozzle is parallel to the seam to be welded.
4. Warn bystanders to shield their eyes. Lower your helmet.
5. Press the torch switch to strike arc and, as the weld is deposited push the torch slowly along the seam at a constant speed.

WARNING







The wire, contact tip and wire feed mechanism are 'live' when the torch switch is pressed.

6. Using the wire feed speed control, adjust for a 'crisp' sounding arc.

NOTE





Low settings of wire feed speed will cause a long drawn out arc and spattering, high settings of wire feed will cause stubbing.

POSSIBLE WELDING PROBLEMS

Fault		Possible Cause
Wire does not move forward despite rotation of feed rollers		<ol style="list-style-type: none"> 1. Pressure roller inadequately loaded 2. Dirt in wire guide and/or contact nozzle
Irregular wire feed		<ol style="list-style-type: none"> 1. Faulty contact nozzle 2. Dirt in groove of feed roller 3. Feed roller groove faulty
Arc will not strike		<ol style="list-style-type: none"> 1. Poor contact between earth return and workpiece
Arc too long and irregular		<ol style="list-style-type: none"> 1. Voltage too high
Very small arc		<ol style="list-style-type: none"> 1. Voltage too low
Welding fault	Appearance	Possible cause
Pores		<ol style="list-style-type: none"> 1. Incorrect gas flow. Rec. 8-10 l/min. 2. Inadequate gas shielding due to spatter in nozzle 3. Draughty workplace 4. Welding distance too long and/or welding torch wrongly held 5. Damp, oil, rusty workpiece
Poor filling up		<ol style="list-style-type: none"> 1. Welding speed too high 2. Current too low relative to welding speed
Binding faults		<ol style="list-style-type: none"> 1. Irregular movement of torch 2. Voltage too low
Spatter		<ol style="list-style-type: none"> 1. Voltage too high 2. Gas nozzle dirty
Uneven joint		<ol style="list-style-type: none"> 1. Wire tip too long 2. Current too high relative to voltage 3. Welding speed too low
Poor penetration		<ol style="list-style-type: none"> 1. Current too low relative to voltage

NOTE! Faults in the electrical parts such as the control circuits, relays, switches, transformers, etc, should only be attended to by a proficient service technician

WELDING GUIDELINES

MIGET	T mm	WIRE			GAS
	0.8mm	Fe 0.6mm Fe 0.8mm	2.25 1.75	2 2	Ar/CO ₂ Mix
	1.0mm	Fe 0.6mm Fe 0.8mm	3.25 3	2 3	Ar/CO ₂ Mix
	1.5mm	Fe 0.6mm Fe 0.8mm	4.25 3.25	3 3	Ar/CO ₂ Mix
	3.0mm	Fe 0.6mm Fe 0.8mm	- 6.0	- 5.0	Ar/CO ₂ Mix
	3.0mm	Al 1.0mm	10	6	ARGON
	0.8mm	Fe 0.6mm Fe 0.8mm	2.25 2	2 2	Ar/CO ₂ Mix
	1.0mm	Fe 0.6mm Fe 0.8mm	2.5 2.25	2 3	Ar/CO ₂ Mix
	1.5mm	Fe 0.6mm Fe 0.8mm	4.25 3.5	3 3	Ar/CO ₂ Mix
	3.0mm	Fe 0.6mm Fe 0.8mm	- 5.5	- 4	Ar/CO ₂ Mix
	3.0mm	Al 1.0mm	10	5	ARGON

MAINTENANCE

All welding equipment should be thoroughly inspected, tested and serviced at least annually. More frequent checking will be required when the equipment is heavily used. Should this equipment fail to operate correctly, stop work immediately and have the problem investigated. Maintenance work must be performed by a trained person and electrical work by a qualified electrician.

WARNING

Switch off and disconnect the unit from the mains supply before undertaking any maintenance tasks.

DAILY TASKS (OPERATOR)

1. Check all welding and electrical cables for signs of damage, cracking or general deterioration. Have defective cables replaced.
2. Check that all welding connections are in good condition. In particular inspect the work return to workpiece connections and check all welding connections at the power source output and the wire feed unit are secure.
3. Inspect the wire feed unit drive mechanism ensuring the drive rolls are in good condition and correct for the wire in use. Remove any dust or debris that may have collected around the rolls or drive stand. Ensure the wire reel is correctly fitted and its retaining nut is in place.
4. Check the welding torch for signs of damage. Replace any suspect parts.
5. Check the overrun adjustment setting (see notes on page 7).

SIX MONTHLY (MAINTENANCE DEPARTMENT)

WARNING

Switch off and disconnect the unit from the mains supply before undertaking any maintenance tasks.

1. Using a soft brush and/or a supply of clean dry compressed air clean out the inside of the power source. Remember to wear suitable eye and mouth protection.
2. Inspect the incoming chassis ground connection ensuring it is clean and tight.
3. Inspect the welding output dinse connections for signs of overheating or cracking. Replace if necessary.

ANNUALLY (QUALIFIED ELECTRICIAN OR APPROVED SERVICE CENTRE)

WARNING

Before carrying out these tests, ensure that the unit is isolated from the electrical mains supply.

Preparation

1. Join together the live and neutral wires which are connected to TB1.
2. Connect together the welding output SK1 and work return socket SK2.
3. Close the On/Off switch S1.
4. Remove the pcb completely.
5. Disconnect the earth lead from the fan F.
6. Mechanically close the main contactor MC1/4.


Continuity

Using an ohm meter of 10,000 ohms per volt or better (e.g. AVO) check for continuity between the mains input cable earth wire and chassis earth points - see wiring diagrams.


Insulation Tests

With an insulation tester (e.g. Megger), check for readings greater than 100K ohms between:


- (a) The mains input wires and output terminals
- (b) The mains input wires and earth wire.



ITEM	DESCRIPTION	PART No
1	Potentiometer	1415010
-	Knob for Item 1	500/11003
2	On/Off Switch	1411458
3	Fault Indicator	1413447
4	Side Panel	1415011
5	Side Panel	1415012
6	Six Position Switch	1411459
-	Knob for Item 6	1413442




ITEM	DESCRIPTION	PART No
1	Castor Assembly	1415006
2	Central Adaptor	1413108
3	Wire Feed Motor	1415007
4	Reel Hub Assembly	1411467
5	Cylinder Support	1415008
6	Axle & Rear Wheel Assembly	1415009
7	Wheel	1413488



ITEM	DESCRIPTION	PART No
1	Solenoid Valve	1411464
2	Main Transformer	1415013
3	Fan	1411477
4	Diode Bridge	1415014
5	Auxilliary Transformer	1415015
6	Contactor	1411456
7	P.C.B	1415016
8	Thermostat	1415017
9	Inductor	1415018
-	Fuse 3.15A 20 x 5mm	1411486
-	Fuse 1.6A	1415019

Fuse Holder for 1411486 is 1411514.



ITEM	DESCRIPTION	PART No
1	Locating Pin (Pressure Arm)	1415002 NA
2	Guide Tube Liner	1413456
3	Guide Tube	1413454
4	Central Adaptor	1413108
5	Feedplate	1413874
6	Feed Roll Retaining Screw	1413104
-	Woodruff Key	1411549
7	Feed Roll 0.6/0.8 (H)	1411470
-	Feed Roll 1.0mm (S)	1411489
	Note (Aluminium Only)	
8	Inlet Guide	1413103
9	Locating Pin (Pressure Device)	1413861
10	Pressure Device	1413897
11	Pressure Arm Complete	1415001